

UNITED INTERNATIONAL UNIVERSITY

COURSE NO. CSE 124 (ELECTRONICS LABORATORY)

Exp. No. 1: Circuits, Meters and Measurements

Aim:

To understand:

- Basic electrical components and equipment
- Simple measurements
- Basic voltage and current laws
- Linear and non-linear components

Equipment

- Trainer Board
- Multimeters
- Ammeters
- Wires
- Resistors: 100 ohms, 120, 1K
- LED (Light Emitting Diode) any colour

Two Terminal Devices




Figure 1. Symbols and pictures

Multimeter





Multimeter wired



Multimeter wired for mA



Multimeter wired for DC 20 Amps range

Figure 2. Various multimeter connections

Prototyping board





Figure 3. Detail of white proto board






Figure 4 - View of insides of proto boards

Part A – Linear Components (Ohm's Law)

Activities:

To find the relationship between current and voltage in a resistor

Procedure:


Vary the power supply so as to measure the voltage, V_1 , for the values of current given in the table.

Plot V_1 versus I_1 .

You should get a straight line through the origin as this is a Linear component.

The slope of the line should be the resistance.

Vs				
Voltage V1				
Current I1				



Part B - Non-linear component.

Activities:

To find the relationship between current and voltage in a diode (LED)

Procedure:

Vary the power supply so as to measure the voltage, V_1 , for the values of current given in the table.


Plot V_1 versus I_1 .

This is a Non-Linear component.

The slope of the line should be the resistance.

Vs				
Voltage V1),	
Current I1				

The shorter LED lead is the cathode, which is connected to the negative supply.



Report:

- Objectives
- Apparatus
- Part A: Linear Components
 - o Circuit Diagram
 - o Data Table
 - o I~V curve of resistor (use graph paper)
- Part B: Non-linear Components
 - o Circuit Diagram
 - o Data Table
 - o I~V curve of diode (use graph paper)
- Q/A:
- Why is ammeter connected in series whereas voltmeter connected in parallel?